



LISTES DE PIÈCES

MODELE RS 232




RS232 MACHINE BODY REPLACEMENT PARTS LIST

KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	690 15000 00	1	Casing	35	697 45006 00	1	Nut (suction pipe joint)
2	690 15001 00	1	Suction joint	36	697 40070 00	1	Suction mouth strainer
3	692 10010 00	1	Mechanical seal compl.	37	698 65021 00	1	Suction pipe joint
4	691 15004 00	1	Cover	38	691 45000 00	1	O-ring
5	691 15002 00	1	Hose joint	39	6909 50120 0	1	Label
6	697 10010 01	1	Seal ring receiver compl.	40	697 40060 00	1	Liquid drug strainer
7	697 15010 00	1	Impeller / <i>Claw 692 11010 00</i>	41	690 55000 00	1	Fuel tank
8	697 25002 00	1	Plug	42	690 55001 00	1	Fuel pipe
9	697 25001 00	1	Plug packing	43	551 65005 00	1	Packing (B)
10	0306 11999 0	1	Snap ring (outer)	44	691 50010 00	1	Fuel tank cap compl.
12	691 45003 00	1	Float switch compl.	45	0641 27999 0	1	Fuel filter
14	691 80020 01	1	Middle cord compl.	46	0642 00990 1	1	Fuel strainer
15	690 30030 00	1	Tank bracket compl. (A)	47	6909 50140 0	1	Label
16	690 30040 00	1	Tank bracket compl. (B)	48	690 80040 00	1	Throttle lever compl.
17	690 35001 00	1	Tank stay	49	690 85000 00	1	Throttle wire compl.
18	0561 15999 2	1	Hose clamp.	50	690 85003 00	1	Spiral tube
19	690 45004 00	4	Tank fitting plate	51	698 50080 00	1	Stop button compl.
20	690 45005 00	4	Seal washer	52	698 55021 00	1	Dust-proof cap
21	690 90050 00	1	Shoulder band set	53	690 80020 00	3	Vibration-proof rubber compl.
22	690 90100 00	1	Waist pad compl.	54	690 85004 00	1	Pump bracket
23	690 45006 00-2	1	Liquid drug tank	55	0100 05997 0	4	Bolt (M5 x 25)
24	690 45001 00	1	Stir nose	56	0100 06990 0	4	Bolt (M6 x 40)
25	690 45002 00	1	Suction nose	57	0170 04999 0	1	Nut (M4)
26	698 45018 00	1	Cap	58	0170 06999 0	11	Nut (M6)
27	690 45003 00	1	Packing (lug)	59	0200 06993 0	17	Washer (M6)
28	697 40010 00	1	Liquid drug tank cap compl.	60	0200 06994 0	5	Washer (M6)
29	697 15000 00	1	Jack nut (stir)	61	0203 05999 0	4	Spring washer (M5)
30	697 15001 00	1	Nipple (stir)	62	0140 06995 0	6	Screw (M6 x 12)
31	697 15002 00	1	Fountain plate (stir)	63	0140 06996 0	4	Screw (M6 x 16)
32	697 15003 00	1	Fountain plate packing	64	00626 1009 1	2	O-ring
33	697 15004 00	1	Hose protection coil	65	00626 2067 1	1	O-ring
34	697 15005 00	1	Binding wire	66	00312 0400 0	1	Washer (M4)




EC02EHR (RS232) ENGINE BODY REPLACEMENT PARTS LIST

KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	521 10030 00	1	Crank case compl. (incl. 2~4)	30	0650 14981 0	1	Spark plug
2	0440 12999 1	2	Oil seal	31	521 50010 00	1	Recoil starter compl. (incl. 32~45)
3	0600 12992 0	2	Ball bearing	32	521 50020 00	1	Recoil compl. (incl. 33~40)
4	521 15004 00	1	Crank case packing	33	521 50021 10	1	Starter knob
5	523 15000 00	1	Cylinder	34	521 50020 30	1	Spiral spring
6	523 15002 00	1	Cylinder packing	35	521 50020 60	1	Starter rope
7	523 20020 01	1	Crankshaft compl.	36	521 50020 20	1	Reel
8	523 25002 00	1	Piston	37	502 50010 30	1	Rope guide
9	524 25001 00	1	Piston pin	38	521 50020 10	1	Starter case
10	510 25010 00	1	Piston ring	39	510 50151 10	1	Set screw
11	0665 07999 0	2	Clip	40	521 50020 40	1	Washer
12	00632 0310 1	1	Woodruff key	41	521 50030 00	1	Starter pulley compl. (incl. 41~45)
13	0610 10997 0	1	Needle bearing	42	521 50030 10	1	Starter pulley
14	521 30050 00	1	Muffler compl.	43	521 50030 20	1	Ratchet
15	523 35006 00	1	Muffler cover	44	521 50030 30	1	Return spring
16	601 35002 00	1	Muffler gasket	45	521 50030 40	1	E-ring
17	522 35003 00	2	Muffler clamping bolt	46	690 95024 00	1	Label (Main)
18	0200 06997 0	2	Washer	47	0119 05995 0	2	Bolt (socket head) (M5 x 18)
19	523 350000 0	1	Insulator	48	00435 0525 0	3	Screw ass'y (M5 x 25)
20	523 35002 00	2	Insulator packing (float)	49	00436 0514 0	4	Screw ass'y (M5 x 14)
21	523 35001 00	1	Carburetor bracket	50	00431 0518 0	2	Screw (pan head) (M5 x 16)
22	520 58801 00	1	Fan cover	51	00411 0520 0	2	Screw (counter sunk head) (M5 x 20)
23	520 58802 00	1	Cylinder cover	52	0140 05999 0	2	Screw (M5 x 20)
24	521 58803 60	1	Windbreak	53	0180 05999 0	3	Screw (M5)
25	520 70010 00	1	Magneto compl. (incl. 26, 27)	54	00113 0518 0	1	Bolt ass'y
26	520 70010 10	1	Flywheel	55	00312 0800 0	1	Washer
27	520 70010 20	1	Ignition coil				
28	0241 05995 0	1	Grommet (secondary)				
29	510 70080 60	1	Plug ass compl.				



EC02EHR (RS232) CARBURETOR **REPLACEMENT PARTS LIST**

KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	523 60060 00	1	Carburetor compl. (incl 2~33)	26	510 60484 40	1	Cleaner body ass'y
2	523 60010 10	1	Body cap	27	510 60360 50	2	Screw (M4 x 10)
3	510 60484 30	1	Cable adjuster lock nut	28	523 60011 40	1	Air cleaner
4	510 60424 10	1	Cable adjuster	29	523 60011 50	1	Flange packing
5	510 60480 30	1	Throttle spring	30	523 60011 60	1	Throttle valve
6	510 60480 40	1	Throttle spring receiver	31	523 60012 10	1	Rubber cap
7	523 60041 20	1	Jet needle (A146 3/5)	32	523 60040 60	1	Reverse blow preventer
8	510 60480 50	1	E ring	33	510 60262 50	1	O-ring
9	510 60482 30	1	Slow stop screw				
10	510 60482 40	1	Stop screw spring				
11	523 60041 30	1	Needle jet (ø2.08)				
12	523 60041 10	1	Main jet (ø56)				
13	523 60040 10	1	Float chamber ass'y				
14	580 60483 30	1	Float chamber packing				
15	523 60041 40	1	Float				
16	523 60042 10	1	Float hinge				
17	540 60203 10	1	Hinge pin				
18	523 60041 50	1	Needle valve				
19	523 60041 60	1	Needle valve (CA=2.5 x 0.5)				
20	580 60483 10	1	Body band ass'y				
21	523 60011 10	1	Band bolt				
22	510 60482 50	4	Screw (M4 x 10)				
23	523 60011 30	1	Cleaner cover				
24	510 60485 10	1	Rubber seal				
25	510 60484 60	2	Back screen				



RS232 STANDARD EQUIPMENT & STANDARD ACCESSORIES

REPLACEMENT PARTS LIST

KEY NO.	PART NO.	QTY.	DESCRIPTION
1	691 90010 00	1	Spray hose compl. (incl. 2, 3)
2	691 90010 60	1	Packing
3	691 96011 00	3	Packing
4	691 96001 00	1	Spray pipe (incl. 3)
5	697 96000 00	1	Top cock (incl. 3)
6	690 96001 00	1	3 spout annular head
7	690 90040 00	1	Tool kit (incl. 8)
8	0713 19889 0	1	Box wrench